Fully Motorised Vertical Spindle



Read this manual before use

For European models this manual supports the CE Declaration of Conformity

Retain for future reference

Manuals and Additional Information

Operation

Figure 1 Remote



Figure 2 Fully Motorised Vertical Spindle

Read these instructions in conjunction with the full Vertical Spindle and Compac manual provided.

Our remotes feature a red safety button and a stand-by button, as well as the operation buttons.

MOTORISED ROTATION

1. To rotate the Vertical Spindle, use the buttons labelled with arrows which indicate turning, shown in the second row of buttons down in Figure 1.
2. This operation rotates the gearbox labelled 'Rotation Gearbox' in Figure 2.

MOTORISED GRIPPING / UN-GRIPPING

1. To operate the gripping and un-gripping of your reel (fingers shown in Figure 2), use the buttons in the third row labelled with inward and outward arrows.
2. To operate the un-gripping feature, you will need to hold the red button at the same time. This is a safety feature.
3. When the correct gripping torque is reached, the LED will light up green. This indicates the reel is safe to manoeuvre.

PLEASE NOTE: The LED will also light up green when the reel has been completely released by the fingers.

The button corresponding to the set of arrows moving inwards / towards each other is the operation to GRIP your load.

The button corresponding to the set of arrows moving outward / away from each other is the operation to UN-GRIP the load.

WARNING! ONLY USE ONE OPERATION AT A TIME. E.g. either lift / lower attachment, rotate or grip / un-grip at a time.

READ FULL INSTRUCTION ON OPERATION IN ANY OTHER MANUALS OR DOCUMENTATION INCLUDED IN CORRESPONDENCE.